


SADDLEBAG FITMENT GUIDE

ALL BIKES ARE DIFFERENT, PLEASE USE THIS AS A REFERENCE ONLY

Proper measurements required for fitting saddlebags are as follows:


1. Bags are measured from the back of the bag.

2. Measure side to side (B): From the back of the seat (rider's position) or shock to the back of the turn signal. Measurement should be greater than the top of the bag length(L).



3. Measurement from top to bottom(A): From the bottom of the seat pad or to the top of the fender to the exhaust pipe. Subtract 2" from the measurement, this is your maximum saddlebag height (H) for clearance.

4. Maximum Clearance (MC): The 2nd measurement in (parenthesis) is the maximum clearance for the bag. Longest point to longest point. All throw-over saddlebags must be used in conjunction with a saddlebag support bracket to keep bags from interfering with any operating components. 2" of space must be allowed between the bottom of the bag and top of exhaust pipes for safety.



Re-check clearance when saddlebag is loaded and with passenger to reassure clearance requirements have been met.

5. Easy Brackets: All bags may be used with Easy Brackets quick release mounting systems. Simply remove the throw-over yokes. All bags are designed with a hard flat back for easy installation of Easy Brackets. No additional saddlebag support brackets are required.

6. Softail Models: For motorcycles with a softail suspension system, observe all clearances similar to swing arm suspension instructions.

** Do Not Overload - Recommended Maximum Weight is 15 lbs. per side